




Lenovo 快速安装指南 / Quick Installation Guide


彩色激光多功能一体机 / Color Multi Function Laser Printer
CM7110W
CM7120W




1 揭掉胶条/Remove




2 移除保护条/Remove




3 关闭/Close




1 安装墨粉盒 Installing the toner cartridge




1 打开/Open




2 取出/Take out




3 摇动/Shake




4 放入/Insert



5 关闭/Close




6 拉出/Take out




2 装入纸张 Loading paper




1 打开/Open




2 移除/Remove




3 调整/Adjust




Legal (LGL)



4 放入/Insert




5 关闭/Close




3

连接电源线
Connecting power cord



1 开机/Power on




4

安装驱动程序
Installing software




Windows

1 放入光盘/Insert




2 点击/Click




连接/Connect

USB




OR

Wired Network



OR

Wireless



Mac / Linux

No CD-ROM Drive
没有CD-ROM驱动器


下载 / Download



<http://www.lenovoimage.com>

5

查看用户手册
Viewing the User's Guide



在使用本产品之前，请确保阅读所提供光盘上的用户指南中的安全说明。
Be sure to read the safety guidelines in the User's Guide on the supplied CD-ROM before using this product.