






在使用本机之前，请仔细阅读本手册；将本手册存放在便于查阅的地方，以备日后参考。为了安全正确地使用本机器，在使用之前，请务必仔细阅读《安全信息》中的安全信息。本手册简要说明安装本机的步骤。有关其他信息的详情，请参见光盘上的操作说明。

Read this manual carefully before you use this machine and keep it handy for future reference. For safe and correct use, please be sure to read the Safety Information in "Safety Information" before using the machine. This manual briefly describes the procedure for installing this machine. For more details about other information, see Operating Instructions in the CD-ROM.

1 安装位置

Install Location



- ❖ 电源
120 ~ 127 V, 60 Hz, 10 A
- ❖ Power Source
220 ~ 240 V, 50/60 Hz, 5.3 A






2 打开包装

Unpacking

- 取下塑料袋。
Remove the plastic bag.
- 撕下机器外壳上粘贴的粘性胶带。
Remove the adhesive tape attached on the machine's exterior.



3 装纸

Loading Paper






4 打开电源

Turning on the Power




5 测试打印

Test Printing



6 连接打印机

Connecting the Printer



- 有关打印机设置和配置网络设置的详情，请参见光盘上的操作说明。
- For details about the machine's settings or network configurations, see *Operating Instructions* in the CD-ROM.

7 安装打印机驱动程序

Installing the Printer Driver

- 有关安装打印机驱动程序的详细信息，请参见“打印机驱动程序和手册”光盘上的《驱动安装指南》。
- For details about installing the printer driver, see *Driver Installation Guide* on the "Printer Drivers and Manuals" CD-ROM.