






1

检查组件
Checking the components



Toner cartridge¹
Toner cartridge¹

A5纸张长边进纸限位板
A5 Long Edge Paper
Input Support

快速安装指南
Quick Setup Guide

产品安全手册
Product Safety Guide

USB接口电缆
USB Interface Cable


随机安装光盘
Installer CD-ROM

2

安装硒鼓单元和墨粉盒 / Installing the drum and toner

提示：
拆下保护盖前请左右轻摇墨粉盒数次，使墨粉盒内部的墨粉均匀分布。


NOTE:
Before pull off the protective cover, please gently shake the cartridge from side to side several times to spread the toner evenly inside the cartridge.



硒鼓单元 (取出硒鼓单元。)¹
Drum unit (Take out the drum unit.)¹

3

装入纸张 / Loading paper




使用A5纸张长边进纸时。
To use A5 Long Edge paper.



4

4 设置国家和语言(设备默认语言为中文) / Setting your country and language (The machine shows Chinese as default)



初始化时，可能需要设置您所在的国家和/或选择所需语言 (具体取决于产品型号)。
如有需要，请遵循屏幕提示完成设置。
At initialization, you may be required to set your country and / or choose your language (depending on your product).
If required, follow the on-screen instructions.


若要使用菜单键设置语言 (如有需要) 和任何其他设置或信息
To set your language using the menu keys (if needed) and any other settings or information



用户手册
User's Guide

5 安装完整的驱动程序和软件包 (多功能套装软件) / Installing full driver and software package (Lenovo Software Suite)

Windows®



请遵循屏幕提示完成安装。
Please follow the on-screen instructions to complete the setup.

(仅适用于 Windows® 8)
使用 Adobe® Reader® 打开随机光盘上的 PDF 说明书。
如果安装了 Adobe® Reader® 却无法打开 PDF 文件，请在控制面板中将 “.pdf” 文件关联更改为 “Adobe® Reader®” 。

(For Windows® 8 only)
Use Adobe® Reader® to open the PDF manuals on the CD-ROM.
If Adobe® Reader® is installed but you cannot open the files, change the “.pdf” file association to “Adobe® Reader®” from the control panel.

Macintosh

您可以登录本公司网站免费下载最新设备驱动程序，以便您使用Lenovo设备。请访问以下网站：<https://www.lenovoimage.com/>。
You can download the latest device driver for free from our website, enabling you to use your Lenovo machine as a printer. Visit us at <https://www.lenovoimage.com/>.